

1

BULTOS / PAQUET / PACKAGES / FORFAITS



ATENCIÓN:
Antes de cualquier tipo de actuación sobre la luminaria, se debe desconectar el aparato del suministro eléctrico.

ATENCIÓ:
Abans de qualsevol actuació sobre la lluminària, s'ha de desconectar l'aparell del subministrament elèctric.

CAUTION:
Before any kind of act in the luminaire, you must disconnect the electric device equipment.

ATTENTION:
Avant de n'importe pas dépannage dans la luminaria, on doit déconnecter l'appareil de source électrique.





BENITO NOVATILU	Modelo: APOLO M	Referencia: APAML	
	IP Bloque Óptico: IP Luminaria: Tensión eléctrica y frecuencia:	IP66 IP66 100-277Vac 50-60Hz	
Potencia máxima admisible: Tipo Lámpara:	500W LED		

Ref. APAML

APOLO M

1.



Sustituir cristal roto
Substituir vidre trencat
Replace broken glass
Remplacer le verre cassé




Desechar en recogida selectiva
Llençar en recollida selectiva
Discard in separate collection
Jeter à la collecte séparée



2.




OFF



SAFETY ROPE

3.



AIMING SIGHT

TERMINAL BOX
(Q-04M)


info@benito.com

tel. 93 852 1000 / 961 401 000

BENITO NOVATILU LIGHT se reserva el derecho de modificar sin previo aviso la información contenida en este documento. / NOVATILU LIGHT es reserva el dret de realitzar modificacions als seus productes sense previ avis. / NOVATILU LIGHT reserves the right to change the information contained in this document without prior notice. / NOVATILU LIGHT se réserve le droit de modifier sans préavis les informations contenues dans le présent document.

**BENITO
NOVATILU**

5.



6.

