
Doc. N.° 1SDH000719R0501 - L4099


SACE Tmax XT


SOR/PS-SOR - Sganciatore di apertura cablato e non cablato, per XT1-XT2-XT3-XT4 interruttore fisso/rimovibile .
SOR/PS-SOR - Wired and non-wired opening release for XT1-XT2-XT3-XT4 fixed/plug-in circuit-breakers
SOR/PS-SOR - Arbeitsstromauslöser, verdrahtet und nicht verdrahtet, für Leistungsschalter XT1-XT2-XT3-XT4 vom festen Typ/ Steckbaren.
SOR/PS-SOR - Déclencheur d'ouverture à émission câblé et non câblé, pour disjoncteur XT1-XT2-XT3-XT4 fixe/debrochable.
SOR/PS-SOR - Relé de apertura cableado y no cableado, para interruptor XT1-XT2-XT3-XT4 fijo/removible.

XT1-XT2-XT3-XT4/III-IV




F-P	XT1-XT2-XT3-XT4	
	III	IV
SOR	OK	OK
PS-SOR	OK	OK
N°2 SOR or N°2 PS-SOR	NO	OK
SOR+UVR	NO	OK
SOR+YO2	NO	OK YO2(3P)+SOR(4P)
SOR+3Q	NO	OK SOR(3P)+3Q(4P)






A




Power and productivity for a better world™

B



C


FOR NOT CABLED ONLY



MAX WIRE NUMBER			
WIRE SECTION	0,5 mm²	1 mm²	1,5 mm²
XT1	5	2	2
XT2	13	9	8
XT3	12	9	7
XT4	13	9	8


D

FOR NOT CABLED ONLY




E

FOR ALL :EXAMPLE FOR XT1 - XT2 - XT3 - XT4 - III




F

EXAMPLE FOR XT1 - XT2 - XT3 - XT4 IV ON 3P




G


EXAMPLE FOR XT1 - XT2 - XT3 - XT4 IV WITH SECOND SOR ON 4P




H




I



J



K



For more information please contact:

ABB S.p.A.
ABB SACE Division
Via Baioni, 35
24123 Bergamo - Italy
Phone: +39 035 395 111
Fax: +39 035 395 306 - 433

www.abb.com

Power and productivity
for a better world™