
Doc. N.° 1SDH000719R0615 - L4099


SACE Tmax XT

AUX-C - Contatti ausiliari 250V-24V cablati XT1-XT2-XT3-XT4 (1Q+1SY; 2Q+1SY; 3Q+1SY; 3Q+2SY)
AUX-C - XT1-XT2-XT3-XT4 wired auxiliary contacts 250V-24V (1Q+1SY; 2Q+1SY; 3Q+1SY; 3Q+2SY)
AUX-C - Hilfskontakte 250V-24V, verdrahtet XT1-XT2-XT3-XT4 (1Q+1SY; 2Q+1SY; 3Q+1SY; 3Q+2SY)
AUX-C - Contacts auxiliaires 250V-24V câblés XT1-XT2-XT3-XT4 (1Q+1SY; 2Q+1SY; 3Q+1SY; 3Q+2SY)
AUX-C - Contactos auxiliares 250V-24V cableados XT1-XT2-XT3-XT4 (1Q+1SY; 2Q+1SY; 3Q+1SY; 3Q+2SY)


XT1-XT2-XT3-XT4




F-P



W







S51 ONLY

Power and productivity
for a better world™

	SY/1	SY/2	Q/1	Q/2	Q/3	S51
CAVI CABLES KABEL CÂBLES CABLES	95-96-98	15-16-18	11-12-14	21-22-24	31-32-34	05-06-08
CONNETTORE (W) CONNECTOR (W) STECKVORRICHTUNG (W) CONNECTEUR (W) CONECTOR (W)	JF2	JL3	JG3	JE2	JH3	JG2

F/P







	XT1	XT2	XT3	XT4
1Q+1SY	OK	OK	OK	OK
2Q+1SY	OK	OK	OK	OK
3Q+1SY	NO	OK	OK	OK
3Q+2SY	NO	OK	NO	OK
2Q+2SY+1S51	NO	OK	NO	OK
1S51	NO	OK	NO	OK

1Q+1SY	SY/1+Q/2	-	-
2Q+1SY	SY/1+Q/1+Q/2	-	-
3Q+1SY	SY/1+Q/1+Q/2+Q/3	-	-
3Q+2SY	SY/1+SY/2+Q/1+Q/2+Q/3	-	-
2Q+2SY+1S51	SY/1+SY/2+Q/1+Q/2+S51	1	1
1S51	S51	1	1

W






	XT2	XT4
1Q+1SY	OK	OK
3Q+1SY	OK	OK
3Q+2SY	OK	OK
2Q+2SY+1S51	OK	OK
1S51	OK	OK

1Q+1SY	SY/1+Q/2	2(JE2+JF2)
3Q+1SY	SY/1+Q/1+Q/2+Q/3	4(JE2+JF2+JG3+JH3)
3Q+2SY	SY/1+SY/2+Q/1+Q/2+Q/3	5(JE2+JF2+JG3+JH3+JL3)
2Q+2SY+1S51	SY/1+SY/2+Q/1+Q/2+S51	5(JE2+JF2+JG3+JH3+JG2)
1S51	S51	1(JG2)


A

XT1-XT2-XT3-XT4/F-P




B

XT1/F-P




C

XT1/F-P




D

XT3/F-P




E

XT3/F-P




F


XT1-XT3/F-P




G XT2-XT4/F-P




H XT2-XT4/F-P




I XT2-XT4/F-P




J XT2-XT4/F-P




K XT2-XT4/F-P



L XT2-XT4/F-P




M XT2-XT4/W




N

XT2-XT4/F-P




O

XT2-XT4/W




P

XT2-XT4/W




Q

XT2-XT4/W




R

XT2-XT4/W




S


XT2-XT4/W




T XT2-XT4/W




U XT2-XT4/W



W





For more information please contact:

ABB S.p.A.
ABB SACE Division
Via Baioni, 35
24123 Bergamo - Italy
Phone: +39 035 395 111
Fax: +39 035 395 306 - 433

www.abb.com

Power and productivity
for a better world™