




DE EN FR NL

B.E.G. LUXOMAT®

Montageanleitung für PD9-M-1C/S-SDB-IP65-DE / Mounting instruction for PD9-M-1C/S-SDB-IP65-FC /
Mode d'emploi pour PD9-M-1C/S-SDB-IP65-FP / Montagehandleiding voor PD9-M-1C/S-SDB-IP65-IB

Master/Maitre
PD9-M-1C-SDB-IP65-DE/-FC/-FP/-IB



Slave/Esclave
PD9-S-SDB-IP65-DE/-FC/-FP/-IB